




# Instruction manual for induction hob

Model code: C890i



Contact Cable on 0844 800 3830 or for spare parts [www.4cable.co.uk](http://www.4cable.co.uk)



• Safety Guidelines .....	4
• Environmental Protection .....	4
• After Sales Service .....	5
• Description of Your Appliance .....	5
 1 / INSTALLING YOUR APPLIANCE	
• Proper positioning .....	6
• Building in .....	6
• Electrical connection .....	7
 2 / USING YOUR APPLIANCE	
• Description of the top .....	8
• Cookware for induction .....	9
• Which cooking zone should you use based on your cookware? .....	9
• Description of control panel .....	10
• Powering on /off .....	10
• Adjusting the power .....	10
• Setting the timer .....	11
• child safety use .....	12
• Safety during operation .....	13
 3 / DAILY CARE OF YOUR APPLIANCE	
• Protecting your appliance .....	14
• Maintaining your appliance .....	14
 4 / SPECIAL MESSAGES, DIFFICULTIES	
• During initial use .....	15
• When powering on .....	15
• During operation .....	15
 5 / COOKING CHART	
• Cooking chart for food types .....	16

*As part of our commitment to constantly improving our products, we reserve the right to make changes to them based on technical advances to their technical and functional features and appearance.*



### **Warning**

**Before installing and using your appliance, please carefully read this Guide to Installation and Use, which will allow you to quickly familiarise yourself with its operation.**

## • SAFETY GUIDELINES

We have designed this cooking hob for use by private persons in their homes.

These cooking hobs are meant to be used exclusively for cooking beverages and foodstuffs and do not contain any asbestos-based materials

This appliance is not intended to be used by persons (including children) with reduced physical, sensory or mental abilities, or persons lacking experience or awareness, unless using it with the help of a person responsible for their safety, or under supervision and with prior instruction in its use. Children should be supervised to ensure that they do not play with the appliance.

### • Residual heat

A cooking zone can remain hot for several minutes after use.

An "H" is displayed during this period.

Avoid touching the hot areas during this time.

### • Child safety device

Your hob is equipped with a child safety device that locks its operation after use or during cooking (See "Child Safety use" section).

Do not forget to unlock it before using the hob again.

### • For users of pacemakers and active implants

The functioning of the hob conforms to current electromagnetic interference standards and thus is in total compliance with legal requirements (89/336/CEE directives).

In order to avoid interference between your cooking hob and a pacemaker, your pacemaker must be designed and programmed in compliance with the regulations that apply to it.

#### For Australia only :

- Young children should be supervised to ensure that they do not play with the appliance.
- The appliance is not intended for use by young children or infirm person without supervision.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid hazard.
- Do not install the product if you see any damage on it.

**For Service issues, phone number : 1300 553 720, fax number : 1300 553 719**

Consequently, we can only guarantee that our own product is compliant.

With regard to the compliance of the pacemaker or any potential incompatibility, you can obtain information from the manufacturer or your attending physician.



### **Electrical Danger**

**Ensure that the power cables of any electrical appliances plugged in close to the hob are not in contact with the cooking zones.**

**If a crack appears in the glass worktop, immediately disconnect your appliance to avoid the risk of electric shock.**

**To do this, remove the fuses or use the circuit breaker.**

**Do not use your hob until you have replaced the glass worktop.**

## • ENVIRONMENTAL PROTECTION

This appliance's packaging material is recyclable. Help recycle it and protect the environment by dropping it off in the municipal receptacles provided for this purpose.



Your appliance also contains a great amount of recyclable material. It is marked with this label to indicate the used appliances that should not be mixed with other waste. This way, the appliance recycling organised by your manufacturer will be done under the best possible conditions, in compliance with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment. Contact your town hall or your retailer for the used appliance collection points closest to your home.


We thank you doing your part to protect the environment.

Any maintenance on your equipment should be undertaken by:

- either your dealer,
- or another qualified mechanic who is an authorized agent for Caple appliances.

When making an appointment, state the full reference of your equipment (model, type and serial number). This information appears on the manufacturer's nameplate attached to your equipment.

### • DESCRIPTION OF YOUR APPLIANCE



- Ⓐ Air intake
- Ⓑ Air outlet
- Ⓒ Vitroceramic glass
- Ⓓ Power cord



## • CONNECTION

These hobs must be connected to the mains using a socket in compliance with publication IEC 60083 or an all-pole circuit-breaker device in compliance with the installation rules in force.

Your appliance should be positioned so that the mains switch is accessible.



When power is first supplied to your hob, or after an extended power cut, an indicator light will appear on the control panel. Wait for 30 seconds approximately until this information disappears before using your hob (This display is normal and it is intended, if applicable, for your after-sales service. In all cases, the user of the hob should disregard it).



### Warning


*If the cable is damaged it must be replaced by the manufacturer, its after-sales service or a person with a similar qualification to prevent danger.*

## • Electrical connection of 220-240V ~



## • Electrical connection of 400V 2N ~ - 16A


Separate the 2 phase wires (L1 and L2) before connection.




For a 400 V 2N triphase connection, if your hob malfunctions, check that the neutral conductor is properly connected.

## • Electrical connection of 2x230V 2L+2N ~-16A


Separate the wires before connection.



## • Electrical connection of 400V 3 ~ - 16A




- **DESCRIPTION OF THE TOP**

**C890I**



## • COOKWARE FOR INDUCTION

### • The induction principle



- A** Inductor
- B** Electronic board
- C** Induced electric current

The principle of induction is based on a magnetic phenomenon.

When you place your cookware on a cooking zone and you turn it on, the electronic boards in your cooking hob produce "induced" currents in the bottom of the cookware and instantly raise its temperature. This heat is then transferred to the food, which is simmered or seared depending on your settings.

### • Cookware

Most cookware is compatible with induction. Only glass, terra cotta, aluminium without a special finish on the bottom, copper and some non-magnetic stainless steels do not work with induction cooking.

We recommend that you select cookware with a thick, flat bottom. The heat will be distributed better and cooking will be more uniform.



By choosing cookware that displays this logo on its bottom or on its packaging, you can be certain that it is perfectly compatible with your hob under normal operating conditions. To help you choose, a list of cookware is provided with this guide.

## • WHICH COOKING ZONE SHOULD YOU USE BASED ON YOUR COOKWARE?

Cooking zone	Cookware to use
<b>16 cm</b>	10 ..... 18 cm
<b>18 cm</b>	12 ..... 22 cm
<b>21 cm</b>	18 ..... 24 cm
<b>28 cm</b>	12 ..... 32 cm



### Tip

*To check the suitability of your cookware:*

**Place the vessel on a cooking zone at power level 4.**


**If the display remains on, your cookware is compatible.**

**If the display flashes, your cookware cannot be used with induction cooking.**

**You can also use a magnet to test the cookware.**

**If a magnet "sticks" to the bottom of the cookware, it is compatible with induction.**

## • DESCRIPTION OF THE CONTROL PANEL



- A** Start/stop touch control.
- B** Power level - + touch controls.
- C** Memory function touch control.
- D** Interrupt function touch control.
- E** Max power booster touch control.
- F** Offset programming touch control.
- G** Timer touch controls.

## • POWERING ON

Press the start/stop button for the cooking zone you want to use. A flashing 0 and a bip indicate that the cooking zone is on. You can then choose the desired power level. If you do not select a power level, the cooking zone will automatically turn itself off.

## • POWER OFF

Press the start/stop button for the cooking zone used or the power level "-" button until 0 is displayed.

## • ADJUSTING THE POWER

Press the + power level button, and a bip\* will confirm that your settings from 1 to P (maximum power) are actually taken into account. When it is switched on you can move directly to maximum power "P" by pressing the "-" power level button.



### Tip

*For simultaneous use, favour the use of cooking zones located on opposite sides of the hob.*

*On the same side, the use of a cooking zone at maximum power results in an automatic limitation of the other cooking zone on that side, which is indicated in the power level display.*



## MEMORY FUNCTION

Allows you to access a determined power level at any moment. Press the button (MEM) and the hob will heat up to a determined power level (The power level defined by the manufacturer is 8), but the user can change the value of this power level by following these steps.

Modification of the memory function power (With the hob switched off)

1. Keep the button (MEM) pressed down until a beep sounds.
2. The power level which has been defined will flash on the display.
3. Modify the power level with the "-" and "+" power level buttons (B).
4. Press the button (MEM) again to validate the operation.
5. Switch off the hob.



## INTERRUPT FUNCTION

This allows you to always be able to trip the power for a certain time. This gives the user total flexibility.

1. Start with the hob switched on and a determined power level.
2. Press the button (INT) and then you can enter the new power level and the time which it is going to be active. The power level is adjusted with the "-" and "+" buttons in zone (B) and the duration is adjusted using the "-" and "+" buttons in zone (G).
3. Then validate by pressing the button (INT).
4. The new power level is displayed with a dot.
5. Once the time has passed, return to the initial position and the dot will disappear.



## MAX POWER BOOSTER

The cooking areas are equipped with a "BOOSTER" function. This function means that the maximum temperature can be obtained quickly.


1. Press the power level button. The hob power display will display (bo) and the hob will start to give maximum power.

2. Once the hob has heated up, select the chosen power level by pressing the “-” power level button in zone “B”. The “BOOSTER” function will be cancelled by pressing any other power sensor associated with the hob, or with the on/off sensor.


## **OFFSET PROGRAMMING**

This allows you to adjust the finishing time and the duration of this cooking session.

1. Switch on the hob of your choice, using the button.

2. Press the  button and it will display the current time. If the time is correct, go to point 4, and if not, adjust the time.

3. **ADJUSTING THE CURRENT TIME** : Use the “-” and “+” power level buttons in zone (B) to change the hour and use the “-” and “+” timer buttons (G) to adjust the minutes.

4. Validate the time by pressing the  button (the digits will then flash).


5. Adjust the time to when you wish cooking to finish with the “-” and “+” buttons from zones (B) and (E).

6. Validate by pressing the  button.

7. Adjust the cooking time using the “-” and “+” timer buttons in zone (G).

8. Validate by pressing the  button.


9. Define the chosen power level for cooking with the “-” and “+” power level buttons from zone (B).

10. Validate the power by pressing the  button.

11. Once programmed, it displays (Auto) and then the digits go off and only a red dot remains lit.

**IMPORTANT** : Offset programming cannot be used at the same time on more than one hob.

## • **SETTING THE TIMER**



### To use the timer:

- Switch on the cooking zone and adjust the power level.
- Select the timer button of the cooking zone.
- Press + or - until you reach the desired setting for your cooking time. For long durations, press - to reach 99 minutes directly.
- The timer starts counting only if the cooking zone is covered with an item of cookware.
- When the cooking is finished the zone switches off, the timer indicates 0, and you are notified by a **sound signal**.
- Press any button to stop the beeping.

### To change the timer settings:


- Select your timer
- Press on + or -.

### To stop the timer:

- Select your timer
- Press twice on + and-.

## • ACOUSTIC SIGNAL

It is possible to silence the appliance, or deactivate the acoustic signals. They can only be activated or deactivated when the hob top is switched off.



- In order to deactivate the acoustic signal, press simultaneously on the "+" power commands and "+" of ☺ on the keypad for the right or rear right cooking zone (depending on the model) until the "bE Ep" symbol appears, keep pressing until the digits disappear.
- In order to activate the acoustic signal, press simultaneously on the "+" power commands and "+" of ☺ on the keypad for the right or rear right cooking zone (depending on the model) until the "bE Ep" symbol appears, and an acoustic signal sounds, then stop pressing the buttons.

## • CHILD SAFETY" USE




Your hob has a child safety device which locks the controls when the hob is not in use (when cleaning for example) or when it is being used for cooking (to maintain your settings). Due to safety reasons, only the "stop" control is always active. It authorises a heating zone to be switched off even when the hob is locked.


### • How do you lock your hob?

Maintain pressure on the lock key until the led on top lights up and a beep confirms your maneuver.

### • Hob locked when in operation

The display of cooking zones in operation alternately indicates power and the locking symbol .

When you press the **power** or **timer** controls for the zones in operation, the lock led lights up. It will switch off after a few seconds. Only the "stop" control remains on at all times.

For cooking zones that are not in operation, the  symbol and the led light up when you press the "**start/stop**" controls. This display will switch off after a few seconds.

### • The hob is locked when switched off

The led above the lock key is switched off. Press this control briefly to switch on the led. The led displays when you press the **start / stop** key in any zone.

### • How do you unlock your hob?

Press the lock control until the led switches off and a double beep confirms your maneuver.



#### Tip

**Remember to unlock your hob before using it again (see chapter on "child safety use").**

## • SAFETY DURING OPERATION

### • *Residual heat*

After intensive use, the cooking zone that you have just used can remain hot for several minutes.

An "H" is displayed during this period.

Avoid touching the hot areas during this time.

### • *Temperature limiter*

Each cooking zone is equipped with a safety sensor that constantly monitors the temperature of the bottom of the cookware. In the event that an empty vessel is left on a cooking zone that is on, this sensor automatically adjusts the power output of the hob, thereby avoiding any risk of damage to the cookware or the hob.

### • *"Small Items" safety*

A small object (such as a fork, a spoon, a ring, etc.) left alone on the hob is not detected as a piece of cookware.

The display flashes and no heat is produced.




### **Warning**

**Several small objects together on a cooking zone may be detected as cookware.**

**If the display remains on: power may be supplied and the objects may be heated.**

## • *Protection against overflows*



The hob may shut down (with the adjacent symbol in the display) automatically in any of these three situations:

- Overflow that spills onto the touch controls.
- Damp towel placed over the touch controls.
- Metallic object placed on the touch controls.

Clean the hob or remove the object, then begin cooking again.

### • *Auto-Stop system*

If you forget to switch off a cooking zone, your hob has an "Auto-Stop system" safety function which automatically cuts off the power to the cooking zone, after a predefined period (between 1 and 10 hours depending on the power used).

If this safety system is used, the cutoff to the cooking zone is displayed as "AS" or "A" on the control panel and a "bip" sounds for about 2 minutes. Simply press any of the control buttons to stop this.

A double bip will confirm your action.

## • PROTECTING YOUR APPLIANCE

Avoid hard shocks from cookware:

The vitroceramic glass worktop is very sturdy; however, it is not unbreakable.

Do not place any hot lids flat on your cooking hob. A suction effect may damage the vitroceramic surface.

Avoid dragging cookware across the surface, which may in the long-term result in the degradation of the decorative finish of the vitroceramic top.

Avoid placing cookware on the frame or cover (depending on the model).

Avoid using cookware with rough or bumpy bottoms: they can capture and transfer particles that may produce stains or scratches on your hob.

***These defects that do not result in appliance malfunction or do not make it unsuitable for use are not covered by the warranty.***

Do not store cleaning products or flammable products in the cabinet underneath your cooking hob.

Do not heat unopened canned goods; they may burst.

Of course, this precaution applies to all types of cooking.

Never use a sheet of aluminium for cooking. Never place items wrapped in aluminium foil or packaged in aluminium dishes on your cooking hob.

The aluminium will melt and permanently damage your cooking appliance.

Objects not intended for cooking should never be placed on the hob (risk of powering on, scratches, etc.).

Steam cleaning should never be used. The steam jet could damage your hob.

## • MAINTAINING YOUR APPLIANCE

TYPE OF STAINS/SPOTS	USE	WHAT TO DO
Light.	Disinfectant sponges.	Thoroughly moisten the zone to be cleaned with hot water, then wipe off.
Accumulation of baked-on soil. Overflow of sugary preparations, melted plastic.	Disinfectant sponges. Scraper for glass.	Thoroughly moisten the zone to be cleaned with hot water. Use a scraper for glass to remove the large bits, follow with the rough side of a disinfectant sponge, and then wipe off.
Rings and hard water residue.	White spirit vinegar.	Apply warm white vinegar to the stain, let stand, then wipe with a soft cloth.
Shiny metallic streaks. Weekly maintenance.	Cleaning agent for vitroceramic glass.	Apply a cleaning agent for vitroceramic glass (preferable one with silicone for its protective properties) to the surface.



Cream



Special disinfectant sponge  
for delicate dishes



Powder




Scouring sponge



### • During initial use

YOU OBSERVE THAT:	POSSIBLE CAUSES:	WHAT SHOULD YOU DO:
An indicator light appears.	Working normally.	Nothing.
Your installation blows a fuse.	The electrical connection of your hob is incorrect.	Verify the connections. See the "Electrical connection" section.
Only one side works.		
The hob produces an odour during the first cooking sessions.	New appliance.	Operate each cooking zone for 30 minutes with a saucepan full of water.

### • When powering on

YOU OBSERVE THAT:	POSSIBLE CAUSES:	WHAT SHOULD YOU DO:
The hob is not working and the indicator lights on the control panel are not on.	The appliance is not receiving electricity. The electrical supply is defective or the electrical connection is incorrect.	Inspect the electrical circuit breaker and fuses.
The table is not working and another message is displayed.	The electronic board is operating poorly.	Call the After-Sales Service Department.
The hob does not function, the information  is displayed.	The hob is locked.	See chapter on using the child safety system.

### • During operation

YOU OBSERVE THAT:	POSSIBLE CAUSES:	WHAT SHOULD YOU DO:
The hob stops working and it emits a beep approximately every 10 seconds and a  or "F7" is displayed.	There was an overflow or an object is in contact with the control panel.	Clean the hob or remove the object, then begin cooking again.
A series of small  or "F7" is displayed.	The electronic boards heated up.	See "Built-In" section.
After turning on a heating zone, the indicator lights on the control panel continue to flash.	The cookware used is not suitable for induction or is less than 12 cm in diameter (10 cm for the 16-cm cooking zone).	See section on cookware for induction.
The saucepans make noise during cooking. Your hob makes a clicking sound during cooking.	This is normal with some types of cookware. This is caused by the transfer of energy from the hob to the cookware.	Nothing. There is no risk, neither to your hob nor to your cookware.
The fan continues to function a few minutes after your hob is turned off.	Cooling of the electronic components. Working normally.	Nothing.



### Warning

**In the event that there is a break, crack or opening—even minor—in the vitroceramic glass, immediately disconnect your appliance to avoid the risk of electric shock. Contact the After-Sales Service Department.**

## • COOKING CHART

		FRY BRING TO A BOIL	COOK/BROWN RETURN TO BOILING BOILING LIGHT BROTHS		COOK/SIMMER			KEEP WARM	
		P 9 8	7	6	5	4	3	2	1
<b>SOUPS</b>	<b>BROTHS</b>					●			
	THICK SOUPS						●		
<b>FISH</b>	COURT BOUILLON			●					
	FROZEN FOODS				●				
<b>SAUCE</b>	THICK, FLOUR-BASED					●			
	BUTTER-BASED WITH EGGS (BEARNAISE, HOLLANDAISE)					●			
	PREPARED SAUCES	P 9 8	7	6	5	4	3	2	1
<b>VEGETABLES</b>	ENDIVES, SPINACH						●		
	DRIED BEANS						●		
	BOILED POTATOES				●				
	GOLDEN BROWN POTATOES				●				
	SAUTEED POTATOES				●				
	DEFROSTING VEGETABLES						●		
<b>MEAT</b>	MEAT, NOT TOO THICK		●						
	STEAKS, IN SKILLET			●					
	GRILLED MEATS (CAST IRON GRILL)		●						
<b>FRYING</b>	FROZEN FRENCH FRIES	●							
	FRESH FRENCH FRIES	●							
		P 9 8	7	6	5	4	3	2	1
<b>MISCELLA- NEOUS</b>	PRESSURE COOKER (ONCE IT STARTS WHISTLING)					●			
	COMPOTES				●				
	CRÊPES			●					
	CRÈME ANGLAISE		●						
	MELTED CHOCOLATE								●
	JAMS				●				
	MILK		●						
	EGGS, FRIED			●					
	PASTA			●					
	JARS OF BABY FOOD (DOUBLE BOILER)				●				
	MEAT STEW		●						
	SPANISH RICE						●		
	RICE PUDDING						●		